



SW1200 Post & Cable

Operator & Maintenance Manual



Recommended Maintenance:

1. Quarterly & Annual Inspections
2. Equipment replacement
3. Coating Repair



Quarterly & Annual Inspections:

1. Inspect system at minimum once annually. Quarterly inspections are recommended.
2. Identify any system components requiring replacement.
3. Communicate parts to GGT Parts & Service department for ordering.

Equipment Replacement (common spare parts):

1. U-bolt w/ nut and washer – 610711, 610712
2. Roll Pin - 610714
3. 1-3/4" Socket Pin - 500893
4. 1-1/4" Spelter Socket - 610719
5. Epoxy for spelter socket & hardener – 610720, 610790
6. Additional materials available. Please contact GGT.

Coating Repair:

When coating requires touch-up or repair due to rust and/or corrosion, the following recommendations can be applied:

1. Utilizing a wire brush or wire wheel attachment on a grinder, remove all the rust and corrosion from the surface.
2. Utilizing a spray type or paint on type, apply a cold galvanizing compound to the affected area. Follow manufacturer's instructions regarding weather and application of the cold galvanizing compound.
3. Rusted or corroded components such as U-bolts should be replaced.